

SabreBond™ XL300

SabreBond XL300 is one component cross-linking aliphatic PVA adhesive which exceeds the D3 requirements according to EN204. Used for all timber lamination and joinery work, it is also suitable for flat veneer and laminate bonding and responds well to RF curing. SabreBond XL300 sets up very quickly providing short pressing times which will increase production and through-put, it is also sanderable, setting up hard and clear, making it ideal for furniture manufacturing.



Fields of Application

- Moisture resistant gluing of windows, doors and stairs according to EN204/D3.
- Surface bonding of decorative papers.
- Edge gluing with veneers, plastic laminates and solid wood stripes.
- Surface bonding of decorative high pressure laminates in short-cycle presses.
- Cabinet and assembly bonding with medium pressing times and preheating devices.

Physical Properties

Base	PVA Dispersion
Colour	• Wet - White • Dry - Clear
Solids	48-50%
Viscosity	@ 25°C- 6,000 - 8,000 cPs
Ph	3.0 - 3.5

Product Usage

Apply SabreBond XL300 in a thin and uniform coating to one surface. If higher water resistance is required, apply to both surfaces. SabreBond XL300 can be applied using glue spreaders, glue rollers, notched trowels, brushes or other appropriate tools.

Clean application tools with water before adhesive starts to dry and set. Set adhesive needs to be removed mechanically.

The open assembly and setting times largely depend upon the working conditions such as temperatures, moisture, absorbency of materials, glue spreads and tensions of the materials. Best results are obtained under the following conditions:

- Room, material and glue temperature-18 – 20°C
- Wood moisture-8 – 10°C
- Relative humidity-60 – 70%
- Glue spread: for surface bonding-80 – 140 g/m²
for assembly bonding-160 – 180 g/m²
- Pressure depending on type of gluing- 0.1 – 0.8 N/mm²

Minimum pressing times:

- Surface gluing of decorative papers-from 10 seconds
- Surface gluing of high-pressure laminates
- Zin short-cycle presses (90 – 105°C)-from 60 seconds (@ 4 – 6 Bar)
- Assembly bonding-30 minutes
- Board joint and blocks bonding-45 minutes

Shelf Life

1 year from date of manufacture.

Storage

Product should be stored in the original container out of direct sunlight between 5°C and 30°C and protected from freezing. Rotate stock using oldest batches first. Close containers air tight after use. For best performance, use product within 12 months of manufacture.

Safety & Disposal

This material is non-hazardous. Refer to the Material Safety Data Sheet (MSDS) for further information.

Gluing Tips & Procedures

- Preparation and Machining – Careful attention to the machining and preparation of edges before assembling will result in obtaining the strongest possible bonds.
- Planning the edges to be bonded is recommended over against using a circular saw, as saw blades tend to damage the bonding surfaces by tearing the wood fibres as they cut, leaving a rough surface which often requires excessive clamping pressure to bring the two surfaces together; where as a planner shears the fibres longitudinally, leaving them undamaged, with a flat surface, that requires less clamping pressure, leaving an almost invisible glue line.
- Most joint failures are the result of poor preparation or machining, so this process is critical. A factor like dull knives or planner blades will crush and glaze the wood fibres leaving the bonding surface like glass. These glazed fibres will not absorb the adhesive and result in weak adhesion or bond. A simple test is to place a droplet of water onto the surface and if it stays beaded for over 30 seconds, the surface will be glazed.

- Another often challenging area is the gluing of resinous timbers like Teak, Heart Rimu, Jarrah, Mahogany and others that require special preparation before gluing. These timbers have resinous extractives that can concentrate on the surface as the timber dries, making them almost water-resistant and prevents water-borne adhesives from penetrating the surface. The safest way is to dress these timbers immediately before gluing, not letting the dressed timber to sit too long as the resins will rise quickly to the surface again – within an hour or so.
- For the ultimate bond strength, it is imperative also that the adhesive is spread evenly over the entire bonding surface.

DISCLAIMER OF WARRANTY

Manufacturer and distributor of this product make no warranty, express or implied, including, but not limited to any implied warranty of fitness for a particular purpose. No warranty is made as to the use or effects incidental to such use, handling or possession of the materials herein described. User is responsible for determining whether this product is fit for a particular purpose and method of application and assumes all risk and liability associated herewith. Manufacturer liability is limited to replacement of product or reimbursement of purchase cost at its sole discretion. No representative of ours has authority to change this provision which relates to all sales.

New Zealand

+64 6 366 0007
40-42 Cambridge St South
Levin 5510

Melbourne

+61 3 8657 5507
67 Gateway Blvd
Epping, VIC 3076

Sydney

+61 2 9098 8244
Level 6, 10 Herb Elliott Ave
Sydney Olympic Park, NSW 2127